



These installation instructions are of a general nature and are designed to assist suitably experienced tradespeople to install Quietspace Panels to a high standard in common applications.

For installation support, please contact your local Autex account manager before you start.

Manufacturer's documents

Autex recommends that all persons engaged in the installation have full knowledge of the product and installation procedure as set out in the most recent edition of these manufacturer's install instructions and related documents. Manufacturer's documents relating to work in this section are:

- Quietspace® Panel Lookbook
- Quietspace® Panel Install Instructions
- Quietspace® Panel Manufacturer's Guarantee
- Autex Interior Acoustics Care & Maintenance Guide

Copies of the above documents are available from the Autex website www.autexglobal.com

Other trades

Prior to installation, consultation with other trades such as HVAC, plumbing, and electrical should be made to establish an order of work that best suits the site.

Transportation, storage & handling

Quietspace Panels must be transported, stored, and handled with care. Avoid abrasion, delamination or distortion, and protect edges from being crushed. Always transport and store Quietspace Panels on a flat, clean, dry surface.

Do not accept damaged product. If product or packaging arrives damaged, note the condition on the freight documents and contact Autex immediately. Goods signed as received in 'good condition' will not be the responsibility of Autex.

Quietspace Panels are a semi-rigid product that can be damaged if not handled with care. Avoid bending the packs and panels as this could cause creasing.

Do not store or drop the panels on their corners or edges as this will cause damage. Boxes and panels should be carried vertically upright by two people.

The work area should be clean and free of dust and other contaminants that could soil the Panels. Clean cloth gloves are ideal when handling Quietspace Panel to ensure panels remain free of handmarks.

Format and finish

Quietspace Panels are supplied as standard 2400 mm (+10 mm/- 0 mm) x 1200mm (+ 5 mm /- 0 mm) sheets to allow trimming to size at installation. Quietspace Panels are packed in boxes for ease of handling, and each box is individually labelled with thickness. Please speak to your Autex account manager to discuss custom length panels if required.

Quietspace Panels are manufactured using non-woven textile production techniques and finished using heat lamination. A tolerance of up to +/- 6% is typical on specified thicknesses.

Quietspace Panels are produced as a dual-density panel to enhance acoustic performance and increase durability. The high-density face should be the exposed surface once install is completed, with the softer side facing the wall or ceiling.

Quietspace Panels are typically supplied 'nude' but can also be supplied factory laminated with Vertiface® fabric. Vertiface fabric has a pile direction, and all panels must be installed with the pile running in the same direction to avoid the appearance of colour variation. The pile direction can be checked by lightly running your hand up, then down the fabric. One way will feel smooth and the other rough. Autex recommends that the installed pile runs down. If installing panels that have had Vertiface prelaminate onto the face, Autex does not recommend butt joining. Butt joined panels are better suited to the Vertiface Overlay installation method (detailed later in these instructions).



Protective fabric facing

To help ensure 'Nude' Quiespace Panels are kept clean throughout the installation process, they are factory applied with a protective spun-bond fabric that is to be removed after the panels are installed.

As each panel is installed, peel a corner of the spun-bond fabric and leave hanging until the job is complete to ensure panels are kept clean through the final finishing stages.

Substrate

Before work commences, all joins, gaps, and cracks in the substrate must be taped with propriety sealing tapes to eliminate the ingress of dust and foreign particles travelling from the construction cavity into the installed product over time. Ensure that the substrates, backgrounds, and adjoining surfaces will allow work to reach the required standard. We recommend that surfaces are prepared to a minimum Level 3 finish.

Very porous surfaces may need to be sealed prior to applying the adhesive. Gloss and semi-gloss finishes should be lightly sanded and dusted clean prior to application of the adhesive.

All surfaces must be clean, dust-free, and dry as dust and moisture will adversely affect the adhesive and may result in lack of adhesion.

Fix to wall substrate

Quiespace Panels should be installed to a clean, flat, or gently curved wall substrate that has been prepared in accordance with the recommendations listed above.

When installing Quiespace Panel on walls, a contact spray adhesive or high grab MS polymer

adhesive is recommended. For ease of installation, we recommend that you install each Quiespace Panel individually. This includes the application of adhesive (contact your local Autex account manager for suitable options) and rolling the panel.

Recommended adhesives

Autex Acoustics recommends a contact-type adhesive or high grab MS polymer adhesive for applying Quiespace Panel to most common substrates. Contact type adhesives are ideal for applying Vertiface as a fabric overlay. Prior to commencing work, we recommend contacting your local adhesive supplier with samples of the Autex products you are installing and the specification of the substrates you are installing to.

It is the installer's responsibility to ensure that any adhesives used are fit for the intended purpose. It also is the installer's responsibility to ensure that the substrate is fit for the application of adhesives and Quiespace Panel.

If using adhesives to install Quiespace Panel, we recommend you consult with your specialist adhesive supplier before you begin. All adhesives should be used in accordance with the adhesive manufacturer's instructions.

Adhere to substrate using contact spray adhesive

Apply the contact adhesive to the Quiespace Panel and substrate as measured for the panel, ensuring the adhesive manufacturer's instructions are followed correctly.

Ensure the adhesive has been tacked-off correctly then fit the Quiespace Panel to the wall. Where joining Quiespace Panels with a butt-join, it is recommended the panel is fitted firmly to the join first, then smoothed out to the edges applying even pressure to ensure adequate adhesive transfer and a strong bond.

Finally, roll the panels towards the butt joins, then roll the entire panel to ensure adhesive transfer and a strong bond. Small wallpaper and vinyl rollers must not be used. A wide roller approximately 100-150 mm is ideal.

Continue as above for all panels until complete.



Adhere to wall substrate using MS polymer adhesive

Refer to the adhesive manufacturer's detailed install instructions in the first instance when available. In the absence of detailed instructions from the adhesive manufacturer, you may refer to the instructions below.

Use a suitable caulking gun in combination with a compatible nozzle when applying MS polymer adhesive. A bead size of not less than 6 mm in diameter is recommended. Apply straight, continuous beads of MS adhesive along the length of the panel (if panels are to be installed vertically) or across the width of the panel (if panels are being installed horizontally) at no more than 300 mm intervals. The outermost adhesive beads must be placed approximately 30-50 mm away from the edge of the panel to avoid the adhesive from leaking at the edges when pressure is applied. See Figure 1 for details.

Ensure that the panel is installed before the adhesive forms a skin. Refer to the adhesive manufacturer's instructions for the skinning or skin over time. If the adhesive becomes skinned, it must be removed and replaced with fresh adhesive prior to the installation of panels. Make sure always that the time between application of the adhesive and installation to the substrate is minimised.

Guide the panel evenly into position and press the panel firmly on the centre, leaving the outer spaces untouched. Using a clean panel roller, apply enough pressure towards the ends and edges of the panel to ensure adequate adhesive contact and spread between the panel and the substrate.

Note: If not enough pressure is applied while rolling, there is a high risk of the panel detaching from the substrate while the adhesive is curing.

Small wallpaper and vinyl rollers must not be used. A wide roller approximately 100-150 mm is ideal.

Where the above recommended bead spacings do not provide adequate wet grab strength to support the panels whilst the adhesive cures, either increase the bead size or reduce the spacing between beads.

Continue as above for all panels until complete.




Figure 1



Fix to ceiling substrate

When Quietspace Panels are installed overhead, high grab MS polymer adhesive is recommended.

Note: Mechanical fixings that are visible after install such as screws are not recommended for Quietspace Panel. When visible mechanical fastenings or screws are desired, consult your Autex Acoustics account manager for details on how to properly install Quietspace Panel using mechanical fixings.

Quietspace Panel should be installed to a clean, flat, or gently curved ceiling substrate that is prepared in accordance with the recommendations listed above. For ease of installation, we recommend that you install each Quietspace Panel individually. This includes the application of a suitable high-quality adhesive (contact your local Autex account manager for suitable options) and rolling the panel.

Refer to the adhesive manufacturer's detailed install instructions in the first instance when available. In the absence of detailed instructions from the adhesive manufacturer, you may refer to the instructions below.

Use a suitable caulking gun in combination with a compatible nozzle when applying MS adhesive. A bead size of not less than 6 mm in diameter is recommended. Apply a straight continuous bead around the perimeter of the panel, leaving a 30-50 mm gap at the corners and ensuring that the perimeter bead is 30-50 mm away from the edges of the panel to avoid the adhesive from leaking at the edges when pressure is applied. Apply internal, continuous beads along the length or across the width of the panel at no more than 300 mm intervals. The internal beads should finish approximately 100 mm away from the perimeter beads. Please refer to Figure 2 for details.

Ensure that the panel is installed before the adhesive forms a skin. Refer to the adhesive manufacturer's instructions for the skinning or skin over time. If the adhesive becomes skinned, it must be removed and replaced with fresh adhesive prior to the installation of panels. Make sure always that the time between application of the adhesive and installation to the substrate is minimised.

Guide the panel evenly into position and press the panel firmly on the centre, leaving the outer spaces untouched. Using a clean panel roller, apply enough pressure towards the ends and edges of the panel to ensure adequate adhesive contact and spread between the panel and the substrate.

Note: If not enough pressure is applied while rolling, there is a high risk of the panel detaching from the substrate while the adhesive is curing.

Small wallpaper and vinyl rollers must not be used. A wide roller approximately 100-150 mm is ideal.

Where the above recommended bead spacings do not provide adequate wet grab strength to support the panels whilst the adhesive cures, either increase the bead size or reduce the spacing between beads. We recommend the use of temporary bracings or double-sided tape to hold the panels in place until the adhesive is completely cured.

Continue as above for all panels until complete.




Figure 2



Cutting Quietspace Panels

Cutting and machining techniques should be trialled on an off-cut prior to cutting panels to ensure the highest quality finish.

Mechanical cutters such as a straight knife cutting machine are ideal for cutting and trimming Quietspace Panels. Caution should be taken to avoid overheating during cutting as this may cause the Panel fibre to melt or fuse slightly on the heated contact points.

Bring the blade to full speed before starting the cut. Secure the Quietspace Panel during cutting to minimise vibration. Follow manufacturers operating and safety instructions, and ensure the use of all appropriate safety equipment and practices when using machine cutters.

Serrated Swibo type knives, insulation saws, and heavy-duty snap-off blade knives can also be used to trim panels to size, and cut holes for services. All cutting tools must be sharp to help ensure an easy, tidy cut.

Caution should be taken with all cutting tools and equipment. Follow manufacturers use and safety instructions, as well as site and individual safe working practices and requirements.

Inspection

Before starting the installation of Quietspace Panels check again that the materials have been supplied as ordered and are free from damage or faults. Check colours and product labels to ensure the product has been supplied correctly.

Any variations or faults must be reported to Autex prior to commencing the installation. No claims will be accepted where the job continues with obvious faults, and no consultation with Autex has taken place. If you cut or install the product, you have accepted the quality.

Where more than one box of Quietspace Panel is required, ensure they are from the same batch as indicated on the product label on each box.

Due to batch to batch variations, we do not recommend joining the different batch lots as this could result in colour variation. Batch numbers should be recorded for future reference.

Variation in thickness and colour fibre blend are inherent features of this type of product. Some variation from panel to panel can occur, and each panel should be checked prior to installation. To accommodate these variations installation may require on-site adjustment by the installer to achieve a flush and professional finish.

Install Quietspace Panels - general

Quietspace Panels should be installed in accordance with these Installation Instructions and as per the specification detail and customer requirements. If there is conflicting information, you must seek clarification from all appropriate parties before proceeding with the work. It is imperative that the installation is planned before cutting and installing any product.

Measure the installation area and check against plans and details. Consider the placement of smaller panel(s); either at one end or two equal smaller panels at each end to mirror either side. Most walls are not perfectly level or straight, and this will need to be managed as part of the install.

Quietspace Panels are supplied to allow trimming to size. We recommend that all panels are measured and squared-up prior to beginning the installation.

Quietspace Panels should be installed vertically (portrait) on walls unless project specifications and requirements state and require otherwise.

Adhesives should be applied strictly in accordance with the adhesive manufacturer's instructions.

Refer to the product label or the technical data sheet for spread rates, tack-off times, climatic requirements, application methods, and equipment required. Adhesive spills or surface contamination should be cleaned immediately following Autex Care and Maintenance instructions.

The job should be progressively checked for appearance, installation quality, and adequate adhesion.

Any variations in colour or appearance must be notified and discussed with your Autex account manager. No claims will be accepted where the job continues with obvious faults and no consultation with Autex has taken place.

When installing Quietspace Panels at lower levels, especially in a school environment, the overlay method should be used. In addition panel edges should be covered by appropriate trims to protect from potential pulling. It is important that all Quietspace Panels covered with Vertiface fabric are fitted with the pile running in the same direction, as this will avoid the appearance of colour variation. You must consider this before you cut panels to the required size. The pile direction can be checked by lightly running your hand up, then down the fabric. One way will feel smooth and the other rough. Autex recommends that the pile runs down.

Colour variation can occur panel to panel. To minimise colour variation panels should be laid out and checked for variation prior to cutting and fitting. Failure to follow this instruction could result in an unsatisfactory finish.



Install Quietspace Panels - edging profiles

Quietspace Panels can be installed using edging profiles.

Plan the installation before beginning by marking out the position of all edge profiles and panel joins, following project plans and specifications. Fit all edging profiles to the wall square and true using adhesive and screws as required. Allow any adhesive to properly cure before installing panels. Measure and cut Quietspace Panels to fit.

Apply adhesives and fit the Quietspace Panel to one edge then press firmly across the entire panel to fit inside all edging profiles. Roll the entire panel to ensure good adhesion and strong bond.

Fit the panels individually and continue until complete.

Install Quietspace Panels - butt joining

While it is not recommended in most situations, Quietspace Panels can be butt-joined. Quietspace Panel thicknesses can vary by up to 6% of declared thickness, so we recommend that the thicknesses of all panels are checked prior to cutting and installing. We recommend trialling the fit of each panel before the application of adhesive. If thickness variances are found, some panels may need packing to achieve a flush finish. Use builder's paper strips on the back of the panel to pack it out as required. Take care to avoid adhesive leakage at the joins when pressure is applied.

Measure and cut Quietspace Panels to fit. Apply adhesives and fit the Quietspace Panel to one edge then press firmly across the entire panel. Roll the panel from the centre out to the joins, and then roll the entire panel to ensure good adhesion and strong bond. Fit panels individually and continue until complete. It is difficult to completely hide joins when butt joining Quietspace Panels so we recommend having a small area installed and approved by the client before proceeding.

Install Quietspace Panels – negative detail

Quietspace Panels are ideally installed with a negative detail between adjoining panels. Design and installation using a sufficient negative detail will significantly reduce the appearance of any panel thickness variations and speed up the install. Rule of thumb is that the negative detail should be equal to the panel thickness.

Quietspace Panel thicknesses can vary by up to 6% of declared thickness, so we recommend that the thicknesses of all panels are checked prior to cutting and installing. We recommend trialling the fit of each panel before the application of adhesive. If thickness variances are found, some panels may need spacing to achieve a flush finish. Use builder's paper on the back of the panel to space it out as required. Take care to avoid adhesive leakage at the joins when pressure is applied.

Plan the installation before beginning by marking out the position of all panel joins, following project plans and specifications.

Measure and cut Quietspace Panels to fit. Apply adhesives and fit the Quietspace Panel to one edge then press firmly across the entire panel. Roll the panel from the centre out to the edges, and then roll the entire panel to ensure good adhesion and strong bond. Fit panels individually and continue until complete.

When installing Quietspace Panels at lower levels, especially in a school environment, using a negative detail is not recommended. In these sort of environments the overlay method should be used. In addition panel edges should be covered by appropriate trims to protect from potential pulling.



Vertiface/Felt (fabric) overlay

Nude Quietspace Panels can be overlaid with Vertiface Felt fabric. Ensure the protective spun-bond facing has been removed before overlaying fabric.

Install Quietspace Panels with a 2-3 mm negative detail to all panel joins, following the 'negative detail' installation recommendations above. This will help minimise visible lines telegraphing through the Vertiface fabric overlay. All panel joins should be bridged by a self-adhesive cloth tape. Tip: use a strip of the protective layer glued in place with the contact adhesive to tape the joins. Gaps greater than 3 mm are not recommended, and the panel should be repositioned and or trimmed to ensure the gap width is correct. Cloth tape should be approx 100 mm wide, be well secured, and suitable for the intended use.

Measure and cut Quietspace Panels to fit. Apply adhesives and fit the Quietspace Panel to one edge then press firmly across the entire panel. Roll the panel from the centre out to the edges, and then roll the entire panel to ensure good adhesion and strong bond. Fit panels individually and continue until complete. Tape all joins in preparation for fabric overlay. We recommend minimising horizontal joins by ordering custom length Quietspace Panels. Please speak to your Autex account manager for advice.

Vertiface should be installed in vertical drops unless specified or otherwise required. Vertiface fabric has a pile direction, and all drops must be installed with the pile running in the same direction to avoid the appearance of colour variation.

The pile direction can be checked by lightly running your hand up, then down the fabric. One way will feel smooth and the other rough. Autex recommends that the pile runs down.

Measure and plan the installation area and check against plans and details. Consider the placement of vertical joins, including smaller drops; either place at one end, or place two equal smaller drops at each end to mirror either side. Most walls are not perfectly level or straight, and this will need to be managed as part of the install.

Vertiface fabric can be installed using spray application contact type adhesive. Apply adhesive in accordance with the adhesive manufacturer's instructions, and hang the first Vertiface drop from the top down, smoothing out from the centre. Roll the entire drop using light pressure to ensure a good bond.

Successive drops should be hung in sequence from the roll, slightly overlapping and double-cut by cutting through both layers of fabric using a sharp, heavy-duty wide snap-off blade knife and straight-edge. Use an alloy flat bar or similar behind the cut to protect the Quietspace Panel.

Remove the trimmings and roll using light pressure to ensure a good bond. Immediately clean any excess adhesives from the join. Joins should be vertical, clean and flat with no gaps, bubbles, or visible compression marks. Continue with successive drops until complete.

Fixtures

Remove cover plates, light fittings, and other fixtures as the work proceeds. Replace, plumb, square and true to line as the work is completed. Packers may be required behind certain fixtures. Further details of these can be obtained from your Autex account manager on request.

Replace

Replace damaged or marked elements.

Clean Up

Clean up as the work proceeds.

On completion

Leave work to the standard required by following all listed procedures. Leave work secure, smooth and free of air bubbles, wrinkles, gaps, stains, and blemishes. Remove debris, unused materials, and waste from the site.

Note: All electrical plumbing, fire safety appliances and fittings should only be removed and reinstalled by an appropriately qualified person.

Service

For more information, contact your Autex account manager or visit our website www.autexglobal.com

● **New Zealand**
702-718 Rosebank Road,
Private Bag 1998
Avondale 1746, Auckland
New Zealand
Freephone 0800 428 839
Phone +64 9 828 9179
Fax +64 9 828 5810

● **Australia**
285 Swan Street,
Richmond, VIC 3121,
Australia
Freephone 1800 678 160
Phone +61 3 9450 6700

● **United Kingdom**
Unit J4, Lowfields Way,
Lowfields Business Park,
Elland, West Yorkshire
HX5 9DA
United Kingdom
Phone +44 0 142 241 8899

● **United States**
1630 Dan Kipper Drive,
Riverside, CA 92507
United States of America
Phone +1 424 203 1813

Autex is an ISO certified organisation encompassing Quality (ISO 9001), Environmental (ISO 14001), and Health and Safety (ISO 45001). Brand names and logos are registered or unregistered trademarks owned or used under license by Autex Industries Limited or other members of the Autex Group. © Copyright 2022 Autex Industries Ltd. All rights reserved. It is the user's responsibility to determine if the product and information presented in this document is suitable for the intended application by engaging a suitably qualified consultant. The information contained in this document is correct to the best of our knowledge at the date of its publication. To verify that this document is the most current publication please check our website or contact your Autex account manager.