

DRAWMER

1970



Dual FET Compressor & Pre-Amplifier

OPERATOR'S MANUAL

CONTENTS

Warranty	2
Safety Consideration	2
<i>Chapter 1 - Introduction</i>	
Introduction	3
Installation	4
Power Connection	4
Audio Connections	5
<i>Chapter 2 - Control Description</i>	
Control Description	6
Hints and Tips	9
<i>Chapter 3 - General Information</i>	
If a fault develops	10
Contacting Drawmer	10
Specification Data	10
Block Diagram	11
Recall Sheet	12

COPYRIGHT

This manual is copyrighted © 2020 by Drawmer Electronics Ltd. With all rights reserved. Under copyright laws, no part of this publication may be reproduced, transmitted, stored in a retrieval system or translated into any language in any form by any means, mechanical, optical, electronic, recording, or otherwise, without the written permission of Drawmer Electronics Ltd.

ONE YEAR LIMITED WARRANTY

Drawmer Electronics Ltd., warrants the Drawmer 1970 Dual FET Compressor & Pre-Amplifier to conform substantially to the specifications of this manual for a period of one year from the original date of purchase when used in accordance with the specifications detailed in this manual. In the case of a valid warranty claim, your sole and exclusive remedy and Drawmer's entire liability under any theory of liability will be to, at Drawmer's discretion, repair or replace the product without charge, or, if not possible, to refund the purchase price to you. This warranty is not transferable. It applies only to the original purchaser of the product.

For warranty service please call your local Drawmer dealer. Alternatively call Drawmer Electronics Ltd. at +44 (0)1709 527574. Then ship the defective product, with transportation and insurance charges prepaid, to Drawmer Electronics Ltd., Coleman Street, Parkgate, Rotherham, S62 6EL UK. Write the RA number in large letters in a prominent position on the shipping box. Enclose your name, address, telephone number, copy of the original sales invoice and a detailed description of the problem. Drawmer will not accept responsibility for loss or damage during transit.

This warranty is void if the product has been damaged by misuse, modification or unauthorised repair.

THIS WARRANTY IS IN LIEU OF ALL WARRANTIES, WHETHER ORAL OR WRITTEN, EXPRESSED, IMPLIED OR STATUTORY. DRAWMER MAKES NO OTHER WARRANTY EITHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. PURCHASER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY SHALL BE REPAIR OR REPLACEMENT AS SPECIFIED HEREIN.

IN NO EVENT WILL DRAWMER ELECTRONICS LTD. BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECT IN THE PRODUCT, INCLUDING LOST PROFITS, DAMAGE TO PROPERTY, AND, TO THE EXTENT PERMITTED BY LAW, DAMAGE FOR PERSONAL INJURY, EVEN IF DRAWMER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states and specific countries do not allow the exclusion of implied warranties or limitations on how long an implied warranty may last, so the above limitations may not apply to you. This warranty gives you specific legal rights. You may have additional rights that vary from state to state, and country to country.

In the interests of product development, Drawmer reserve the right to modify or improve specifications of this product at any time, without prior notice.

DRAWMER

1970

Dual FET Compressor & Pre-Amplifier

SAFETY CONSIDERATIONS

CAUTION - MAINS FUSE

TO REDUCE THE RISK OF FIRE
REPLACE THE MAINS FUSE ONLY WITH
A FUSE THAT **CONFORMS TO IEC127-2.**
250 VOLT WORKING, TIME DELAY TYPE
AND BODY SIZE OF 20mm x 5mm.
THE MAINS INPUT FUSE MUST BE
RATED AT 230V=T250mA and 115V=T500mA.

CAUTION - MAINS CABLE
DO NOT ATTEMPT TO CHANGE
OR TAMPER WITH THE
SUPPLIED MAINS CABLE.

CAUTION - SERVICING
DO NOT PERFORM ANY SERVICING.
REFER ALL SERVICING TO QUALIFIED
SERVICE PERSONNEL.

WARNING
TO REDUCE THE RISK OF FIRE OR
ELECTRIC SHOCK DO NOT EXPOSE
THIS EQUIPMENT TO RAIN OR MOISTURE.



DRAWMER 1970



INTRODUCTION

The 1970 Dual F.E.T. Compressor and Pre-Amplifier builds on a heritage inspired by the first pro audio “tool box” compressor, the illustrious Drawmer 1960, but with a greatly expanded feature set, making it one of the most adaptable mic preamplifier/compressors on the market today. Bringing vintage audio characteristics at an affordable price.

Whilst the feature set of the 1970 is similar to the Drawmer 1960, and the layout of the controls will add to the comparisons, the 1970 has been greatly improved and the DI EQ has been fine tuned to be more accurate than its stable-mate, with various enhancements.

The 1970 use the latest THAT Corporation technology in the 2 mic preamps to provide ultra clean, transparent and precise recordings that can be processed at a later stage using your favourite warming method, be it saturation, valve, transformer or tape. In addition each channel is capable of 66dB of gain, with switchable mic impedance for accurate mic matching to bring out the best from any microphone used. Phase reverse is also included.

From tracking instruments via the dedicated D.I. input, to recording vocals via the ultra clean mic pre’s, recording a guitar cabinet with two microphones, or a singer playing guitar, or even stereo buss compression using the comprehensive linking and mix facilities, the 1970 is the perfect versatile tool for any studio or live event.

- Two THAT Corporation ultra clean mic pre’s with 66dB of gain with phantom power and switchable mic impedance for accurate mic matching
- Separate Line & Mic input XLR’s
- 1 pro quality instrument DI input with low and high EQ.
- Can be used as 2 mono tracking compressors or 1 stereo buss compressor (avoiding image shifting) via the class leading comprehensive linking facilities.
- FETs can be bypassed altogether to provide ultra clean outputs.
- Standard controls such as Threshold, Ratio, Attack & Release, with 8 LED GR Metering on each band.
- Rear panel Side-chain insert points provide even further control.
- ‘Big’ and ‘Air’ Modes Help to preserve the very deep lows and Enhance the sparkling highs.
- Variable Wet/Dry Mix plus Output Gain knobs on both channels give a ‘Parallel Compression’ function without the need for external mixing devices, providing complete and effortless control over the amount of compression used and output levels.
- Two backlit Analogue V.U. Meters with Switchable +10dB Rescale Mode. Time delay relays on outputs for clean power up/down.
- Internal Low Hum Toroidal Linear Power Supply with Voltage Selector Switch.
- Classic Drawmer build quality with rugged steel chassis and aluminium front panel.
- Designed and Handmade by Drawmer in the UK.



INSTALLATION

The 1970 is designed for standard 19" rack mounting and occupies 2U of rack space. Fibre or plastic washers may be used to prevent the front panel becoming marked by the mounting bolts.

- Care should be taken in the choice of positioning. The unit should not be mounted where other equipment obstructs the normal air flow. The unit should not be situated near any heat source, such as a radiator, stove or a high power amplifier that would generate heat.
- The appliance should not be operated near any water or in a location where moisture might be present.
- Always connect the mains earth to the unit.

If the 1970 is to be continuously moved from one location to another, we suggest using additional support in the rack at the rear of the unit.


POWER CONNECTION

The unit will have been supplied with a power cable suitable for domestic power outlets in your country. For your own safety it is important that you use this cable. The unit should **always** be connected to the mains supply earth using this cable, and no other.

If for some reason the unit is to be used at a mains input operating voltage which is different to that as supplied, the following procedure must be carried out.

- 1: Disconnect the unit from the mains.
- 2: Remove the two screws holding the voltage selection cover-plate.
- 3: Remove the cover plate and slide the switch fully to its opposite end.
- 4: Rotate the cover plate one half turn (180 degrees) and refit the two screws.
- 5: Replace with a correctly rated fuse for the selected operation voltage in the IEC socket:
230V-T250mA and 115V-T500mA
- 6: Re-connect to mains power source.

**Never disconnect the earth
from the mains supply**




IEC SOCKET FUSE DRAWER

AUDIO CONNECTIONS


The inputs and outputs are electronically balanced on conventionally wired XLRs (pin 1 screen, pin 2 hot, pin 3 cold and XLR shell is connected to chassis). The 1970 fully conforms to the EMC standards, if the unit is used where it may be exposed to high levels of disturbance such as found close to a TV or radio transmitter we suggest that the screen of the signal cable is connected to the chassis connection on the XLR type connector. The operating level is nominally +4dBu.

If ground loop problems are encountered, never disconnect the mains earth, but instead, try disconnecting the signal screen on one end of each of the cables connecting the outputs of the 1970 to the patchbay. If such measures are necessary, balanced operation is recommended.


The side-chain access points are unbalanced. The side chain feature on the 1970 is part of the compressor feedback stage and would normally be connected to a normalised or semi-normalised pair of patchbay contacts. This would allow the user to insert additional EQ for some de-essing, or frequency conscious compression. The intended use of the audio insert jacks would be to patch in EQ (eg 1961, 1974), reverb or similar processing. Connection is via stereo 1/4" jacks, the wiring convention being: ring is signal send, tip is signal return and sleeve ground.




XLR - OUTPUT (MALE)




XLR - INPUT (FEMALE)



1/4" JACK - INSERT



1/4" JACK - INSTRUMENT INPUT



CONTROL DESCRIPTION

The 1970 shares similar parameters to those found on the Drawmer 1960, and anyone familiar with that or the 1969 will be immediately at home, the difference being that the 1970 has an expanded feature set and therefore more controls, such as variable mic impedance, “Big” and “Air”. With the exception of the Instrument D.I. section, both channels of the 1970 are identical and may be used independently or linked for stereo operation.

**1 INSTRUMENT****Instrument Input**

A 1/4" jack provides a specialised instrument input stage with the addition of both gain and equalisation, suitable for use with both active and passive guitar pickup systems as well as with electronic keyboards.

Gain 0 - 10

A variable control that provides up to 25dB of gain when the Boost Switch is off or 45dB with Boost.

Boost Switch Off - On

When on adds an additional 20dB of gain to the instrument signal.

Bass EQ 0 - 10

Passive equaliser control which provides cut and boost at approximately 50-100Hz, the EQ being approximately flat at position 5.

Treble EQ 1 - 10

Passive equaliser control which provides cut and boost at approximately 5kHz, the EQ being approximately flat at position 5.

Note that, as the Bass and Treble EQ are passive they interact with each other altering the amount of cut and boost and also the centre point of the EQ's as one control effects on the other.

E.Q Switch Off - On

Switches the two equaliser controls out of circuit when a flat response is required (off), or for an 'A/B' comparison of EQ effectiveness.

Bright Off - On

When on adds 12dB of gain at approximately 2kHz-8kHz with a roll off at either side to simulate the voicing of a typical guitar amplifier.

2 MIC

Gain 0 - +66dB

A twelve position microphone preamplifier switch adds gain in 6dB steps from 0dB to +66dB, making it incredibly easy to replicate previous settings and have total control over levels.

3 SOURCE

Select *Mic +48V/Mic 200 Ohm/Mic 600 Ohm/Mic 2.4 kOhm/Line/Instrument*

The source select is a six position rotary switch that, as well as setting the input source, also sets the load impedance of the microphone.

In the +48V Phantom Power switch position the red LED will illuminate to indicate that 48V of dc voltage is being sent down the XLR cable in order to power the electronics of a condenser microphone.

NOTE: DO NOT ACTIVATE THE +48V SETTING UNLESS THE MICROPHONE REQUIRES IT.

The switch can also provide three settings of load impedance in order to aid the matching for a dynamic microphone, at settings of 200, 600 and 2.4k Ohms.

In addition the same switch sets the source to Instrument (via the front panel instrument DI section) and Line (via the dedicated input on the rear panel).

Phase Reverse *Off - On*

This switch reverses the signal polarity, and is often useful when recording an instrument with more than one microphones. If, for example, you record a guitar cabinet with two mics, the two signals could be so similar that they would cancel each other out partially, resulting in a very thin sound. Reversing the phase of one channel would rectify this.

High Pass Filter Switch *Off - On*

The signal path incorporates a switchable high-pass filter (also known as Low Cut), set to 70Hz at a slope of 12dB per Octave, and is used to attenuate low frequency signals that might otherwise prove troublesome, eg. traffic rumble or stage vibration, and let the higher frequencies pass.

4 COMPRESSOR

Link Switch *Off - On*

When linked the signals of both channels are combined and an average control voltage is created to supply the levels for the compressor. The same degree of gain reduction is applied to both audio channels to prevent image shifting which would otherwise occur whenever the left and right signal dynamics varied from each other by any significant degree. When linked the controls of Channel 1 become the master and the controls of channel 2 are unused.

Note, the link switch only links the compressor and has no effect on the output controls.

Threshold *-40.0dB - +20dB*

Determines the input level above which gain reduction will be applied. Soft knee compression takes place for signals exceeding the threshold level by a few decibels, above which level conventional 'ratio' compression is applied.

Big Switch *Off - On*

Big, when on, reduces the side-chain's sensitivity to low frequencies, with the result that less gain reduction is applied at those frequencies, creating the effect that the bass is louder or 'bigger'. The 'BIG' mode enables application in buss compression situations where you still want thick and warm tone yet complete dynamics control.

Air Switch *Off - On*

Air is used to re-introduce high frequencies, which can sometimes be lost after heavy compression, so that it sounds more intimate, detailed and transparent, but without making it sound harsh or introducing any noticeably unnatural artifacts. Cymbals are more vibrant without becoming splashy, and vocals sound more open but without becoming sibilant.

Ratio *1:1 - 10:1*

Ratio determines the amount of compression (attenuation) to be used once the 'soft-knee' region is exceeded. If the ratio is set to 5:1 a signal exceeding the threshold by 5dB will be attenuated down to 1dB above the threshold, and likewise, a signal exceeding the threshold by 15dB will be attenuated down to 3dB above it. A ratio of 1:1 provides no compression, 4:1 is moderate, 8:1 strong, whilst 10:1 would be seen as approaching limiting.

Attack *0.2mS - 100mS*

Sets the rate at which the compressor will respond to input signals that exceed the threshold level.

Release *0.05S - 3.5S*

Sets the time taken for the signal to return to normal after the input level has fallen below threshold.

PGM Switch *Off - On*

When on causes the release times to vary in a manner which automatically adapts to the dynamics of the incoming signal.


Gain Reduction Meter *1, 2, 3, 5, 7, 10, 15, 20 -dB*

An eight segment LED bargraph meter continuously monitors the gain reduction applied by the compressor and gives an indication of the amount of gain required to bring the signal back to its input level after it has been compressed.

5 OUTPUT

Mix *Wet / Dry*


A variable control that mixes a user defined amount of 'uncompressed' signal (dry) with the compressed signal (wet) to create a 'parallel compression effect' without the need for external mixing devices. In this way the amount of overall compression on the signal is under complete control.



Bypass *Off - On*

A fully balanced hard-wire bypass connects the input source directly to the output without passing through the compressor FET's, the mix and gain controls at all. Use this to provide an ultra clean microphone signal.

Note: this can be used to hear an A/B comparison of the compressor, should you wish.



Gain *Off - On*

During compression the signal is attenuated, gain may be required to produce the required output level. Adjust so that the output signal approaches the desired level only on signal peaks.

Link *Off - On*

The Link switch only links the controls of the Output section and has no effect on the linking of the compressor - these are linked by the Link switch in the Compressor section.

With the link switch off the Mix, Gain and Bypass controls of the two channels are independent of each other, this allows for the 1970 to be used to track two independent signals, but also allows for unbalanced stereo signals to be adjusted should image shifting occur during compression. When the link switch is active the left controls become master and adjust both channels, acting as a stereo control.

VU Meter

Two backlit moving coil VU meters monitor the level of the output signal

+10dB Pad *VU - +10dB*

Adjusts the meters to show either normal output level, (and for those working at 'hot' output levels) VU +10dB i.e. with the switch at VU +10dB, when the VU meter reads 0dB the actual level is +10dB.



6 REAR CONNECTIONS

In addition to the instrument jack connector located in the instrument section on the front panel there are also:

Mic Input

Two dedicated microphone inputs via balanced XLR's are located on the rear panel.

Line Input

Two dedicated line level inputs via balanced XLR's.

Side Chain

The side chain connector is part of the compressor feedback stage and would normally be connected to a normalised or semi-normalised pair of patchbay contacts. This would allow the user to insert additional EQ for some de-essing, or frequency conscious compression. Connection is via unbalanced stereo 1/4" jacks: ring is signal send, tip is signal return and sleeve ground.

Output

Two dedicated outputs via balanced XLR's.

7 POWER

I.E.C./Power Switch/Voltage Selector Switch

See the Power Connection section of the manual

Hints and Tips

Mic Impedance

When it comes to mic impedance matching you may have encountered the general rule of thumb that the impedance of the preamp input should be 10X that of the mic to get an input impedance that is appropriate for the mic and to avoid loading the source, however, it is less known that mismatching can create some interesting tonal differences that can be used more creatively. The result will depend on the microphone used, as the tonal changes will be obvious with some mic's but others will hardly alter, and on the material you're working with and also what you're trying to achieve.

The 1970 has 3 settings per mic input: 200, 600 and 2400 Ohms, making it easy for you to explore the various tones.

Recording a Guitar using 2 Microphones

A common technique when recording guitar, to get the perfect tone that you're trying to achieve is to record a single cabinet with two mic's, one for each channel, with one in the centre of the cone and another a few inches away, for example. There are many online tutorials on how to create this technique.

Another widely used technique especially when recording bass guitar, is to record one channel via a mic'd cabinet, and the other directly into the instrument input on the 1970, or via effects using the line input, and blend the two signals at a later stage.

Note that in both cases phase problems can occur so some delay on one of the channels may need to be added.

In both techniques the 1970 is perfect for the job, enabling you to independently control the gain and compression of each channel to the required amounts with ease to get the desired tone/character.

Parallel Compression Made Easy

The Mix control of each channel works in a similar way to that of the parallel compression technique but with the advantage of being one simple knob. It works by adding variable amounts of the uncompressed signal (dry) to that of the compressed signal (wet), effectively reducing the perceived amount of compression taking place. The most effective way of using the control is to set it at the 3 or 4 position, so that a good amount of compression is heard but a little more can still be added should it be required - then set up the compressor as you would normally. Finally introduce the dry signal by rotating the knob clockwise until the perfect amount of compression is found.

Keep it Clean

The mic stage of the 1970 has been designed to provide as clean a recording as possible. The adage being that if you introduce distortion/warmth at the recording stage it can't be removed, and the recording will be stuck with it, but by contrast, if you obtain a clean recording you can add warmth and distortion at a later time, via tubes, saturation, transformers etc, and in a way that gives you complete control over the effect.

The design of the 1970 takes this one step further - a fully balanced hard-wire bypass, located in the output section, connects the input source (the mics and instrument) directly to the output XLR without passing through any of the compressor FET circuitry, or the mix and gain controls at all, and so introducing as little distortion as is possible, and providing an ultra clean microphone signal.



GENERAL INFORMATION

IF A FAULT DEVELOPS

For warranty service please call Drawmer Electronics Ltd. or their nearest authorised service facility, giving full details of the difficulty.

A list of all main dealers can be found on the Drawmer webpages.

On receipt of this information, service or shipping instructions will be forwarded to you.

No equipment should be returned under the warranty without prior consent from Drawmer or their authorised representative.

For service claims under the warranty agreement a service Returns Authorisation (RA) number will be issued.

Write this RA number in large letters in a prominent position on the shipping box. Enclose your name, address, telephone number, copy of the original sales invoice and a detailed description of the problem.

Authorised returns should be prepaid and must be insured.

All Drawmer products are packaged in specially designed containers for protection. If the unit is to be returned, the original container must be used. If this container is not available, then the equipment should be packaged in substantial shockproof material, capable of withstanding the handling for the transit.

CONTACTING DRAWMER

Drawmer Electronics Ltd., will be pleased to answer all application questions to enhance your usage of this equipment. Please address correspondence to:

Drawmer (Technical Help line)
Coleman Street
Parkgate
Rotherham
S62 6EL
UK

Alternatively contact us by E-mail on :

for sales enquiries: sales@drawmer.com
or for technical issues: tech@drawmer.com

Further information on all Drawmer dealers, Authorised service departments and other contact information can be obtained from our web pages on:

<http://www.drawmer.com>

1970 DUAL FET COMPRESSOR AND PRE-AMPLIFIER DATA SPECIFICATION

INPUT

Input Impedance 20k Ohms or greater
Maximum Input Level +21dBu

OUTPUT

Output Impedance 100 Ohms
Maximum Output Level +21dBu into 10k Ohms Load

FREQUENCY RESPONSE

20Hz to 20kHz +/-0.5dB

CROSSTALK

< -75dB @ 1kHz

NOISE AT UNITY GAIN

20Hz - 20kHz >93dB

% DISTORTION (THD & NOISE) @ 1kHz

0dB (ref +4) 0.01%
10dB (ref +4) 0.01%

MIC EIN

-130dB

POWER REQUIREMENTS

230Volt or 115V at 50-60hZ, 30VA

FUSE RATING

T250mA for 230Volt,
T500mA for 115Volt
Conforming to IEC 127-2

FUSE TYPE

20mm x 5mm, Class 3 Timed-Blo, 250Volt working


CASE SIZE


482mm (W) x 88mm (H) x 270mm (D)

WEIGHT

4.2Kgs

BLOCK DIAGRAM





DRAWMER 1970 Session Recall

DRAWMER ELECTRONICS LTD ~ Coleman Street
Rotherham ~ S. Yorkshire ~ UK

© COPYRIGHT DRAWMER ELECTRONICS LTD 2019

Session No.	
Date	
Artist	
Tape Location	